## MaNima Pollux



#### **DATASHEET**



#### Sensor Inputs

Measurements are possible with multiple sensor inputs. These readings can then be used for monitoring and conditions.

#### **Ethernet Switch**

The MaNima Pollux doubles as an ethernet switch. The two ethernet ports on the Pollux are part of the same network.

#### Digital/Potential Inputs

There are 2 digital/ potential inputs available on the MaNima Pollux. These can be used as triggers for actions.

#### **PWM Output**

There are 8 PWM outputs available on the MaNima Pollux. These can be used to control analogue LEDs or devices. PWM frequency up to 300Hz.

#### Redundant Setur

If the Pollux is used in an important installation that must be free from interference and malfunctions, it is possible to have a 2<sup>nd</sup> power source for the Pollux to ensure system reliability.

#### Monitoring

The Pollux has been made with monitoring in mind.

#### MaNima Cloud

Additional modules make it possible to send data to the MaNima Cloud.

#### **Autonomous Operation**

The Pollux is able to fulfil completely autonomous operations without user interaction.

#### Increased Reliability and Protection

The MaNima Pollux is able to measure the current and voltage going through the PWM outputs and inputs.





## **Technical Specifications**

| Po         | ollux mo+H28+C3:J54                             | MaNima Pollux   | MaNima Pollux 30kHz            | MaNima Pollux Industry                     |  |  |  |
|------------|---|---|--------------------------------|--|--|--|--|
|            | Weight  |   | 360 gram                       |  |  |  |  |
|            | Dimensions                                      | 90 x 159 x 58 (B x L x H)   |                                |  |  |  |  |
|            | Mounting  | DIN Rail 35mm   |                                |  |  |  |  |
| <b>6</b> l | IP class  | IP10  |                                |  |  |  |  |
| General    | Storage temperature                             |   | 10°C ~ 60°C                    |  |  |  |  |
|            | Operating temperature                           | 10°C ~ 40°C   |                                |  |  |  |  |
|            | Warranty  | 5 Years   |                                |  |  |  |  |
|            | Directives                                      | CE, RoHs  |                                |  |  |  |  |
|            | Wiring  | Max 1.5mm²   14 AWG   |                                |  |  |  |  |
|            | Own Power Consumtion                            | 1,5W  |                                |  |  |  |  |
|            | Efficiency                                      | Approx. 99,8%   |                                |  |  |  |  |
|            | Input voltage DC1                               |   | 12-48VDC                       |  |  |  |  |
|            | Input voltage DC2                               |   | 12-48VDC                       |  |  |  |  |
|            | Input current DC1                               | 20A   | 10A                            | 20A  |  |  |  |
| Input      | Input current DC2                               | 20A   | 10A                            | 20A  |  |  |  |
|            | Ethernet  | -   | ninal connector: RJ45 bus, 2 x | -  |  |  |  |
|            | NTC / LDR                                       | Edicinet 3 Witch telli  | 2 x RJ11 4 NTC/LDR inputs      | o pino terminar brock                      |  |  |  |
|            | Digital inputs                                  | 2 x RJ11  | 2 inputs                       | 2 x RJ11 2 inputs + 1 x RJ45 8<br>channels |  |  |  |
|            | Min-Max NTC measurement                         | -25°C ~ 100°C,  | 0.1°C degree resolution and -  | +/-10% accuracy                            |  |  |  |
|            | DC1 PWM-outputs                                 |   | 4 ch                           | ·  |  |  |  |
|            | DC2 PWM-outputs                                 |   | 4 ch                           |  |  |  |  |
|            | DC1 Max current output                          | 5A per channel  | 2,5A per channel               | 5A per channel                             |  |  |  |
| Output     | DC2 Max current output                          | 5A per channel  | 2,5A per channel               | 5A per channel                             |  |  |  |
|            | PWM Frequency                                   | 300Hz   | 30kHz                          | Stepless 200Hz to 30kHz                    |  |  |  |
|            | Digital outputs                                 |   | 1 x RJ11 4 digital outputs     |  |  |  |  |
|            | Over voltage protection                         | Yes, up to 50 Volts   |                                |  |  |  |  |
| Electronic | Short circuit protection                        | Fast short circuit protection on outputs and inputs (< 10µs response) |                                |  |  |  |  |
| Protection | On-Board temperature protection                 | Turns off outputs when board is > 60°C.                               |                                |  |  |  |  |
|            | MaNima Configurator                             | v v   |                                |  |  |  |  |
|            | Real-Time temperature monitoring                | ·   |                                | <b>✓</b>                                   |  |  |  |
|            | Real-Time electronic monitoring                 | · · · · · · · · · · · · · · · · · · ·                                 |                                | <b>~</b>                                   |  |  |  |
| Pollux     | Redundant switching inputs and outputs on error | •   | /                              | ~  |  |  |  |
| Features   | Adjust basic NTC / LDR settings                 | <b>~</b>  |                                |  |  |  |  |
|            | Autonomous PWM Dimming                          | · ·   |                                | <b>~</b>                                   |  |  |  |
|            | Set action/failure handlers                     | ·   |                                | <b>✓</b>                                   |  |  |  |
|            | Artnet / sACN compatible                        |   | /                              | <b>~</b>                                   |  |  |  |
|            | Set basic digital and analog contacts           |   | /                              | <b>✓</b>                                   |  |  |  |
|            | Remote control with MaNima Cloud                | <b>)</b>  | Κ                              | <b>✓</b>                                   |  |  |  |
|            | Cloud Database                                  |   | <del>`</del>                   |  |  |  |  |
|            | Cloud Datalogging                               |   | <u>`</u>                       | · ·  |  |  |  |
|            | Cloud Back-up of configurations                 |   | <u>`</u>                       |  |  |  |  |
|            | Cloud Feedback                                  |   | <u>`</u>                       | <u> </u>                                   |  |  |  |
|            | INP compatible                                  | \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \                                 | ζ                              | · /  |  |  |  |
| Industrial | UDP Compatible                                  |   | ζ                              | <b>*</b>                                   |  |  |  |
| Features   | OTA software updates                            |   | <u>`</u>                       | · /  |  |  |  |
| i catules  | Adjust PWM-output                               |   | <u>`</u>                       | <b>*</b>                                   |  |  |  |
|            | Adjust PWM frequency                            |   | <u>`</u>                       | <b>V</b>                                   |  |  |  |
|            | Set advanced digital and analog contacts        |   | <u>`</u>                       | <b>*</b>                                   |  |  |  |
|            | Set (astronomic) timetables                     |   | <                              | <b>~</b>                                   |  |  |  |
|            | Enable Pulse mode                               |   | 7                              |  |  |  |  |





| Feature    |   | Description   |  |  |
|------------|---|---|--|--|
|            | MaNima Configurator                             | Use the MaNima Configurator to adjust or read the parameters of the MaNima Pollux.  |  |  |
|            | Real-Time temperature monitoring                | Use NTC sensors to monitor the temperature of LED Engines. An on-board temperature sensor also measures the temperature of the MaNima Pollux.                                 |  |  |
|            | Real-Time electronic monitoring                 | The MaNima Pollux measures the currents and voltages over its in- and outputs.  |  |  |
| Pollux     | Redundant switching inputs and outputs on error | Use action handlers to switch from outputs or inputs incase of calamities.  |  |  |
| Features   | Adjust basic NTC / LDR settings                 | Adjust maximum and minimum temperatures of LED Engines and dimming curve of POutputs  |  |  |
|            | Autonomous PWM Dimming                          | Autonomously decrease the current of the PWM Output to decrease the generated heat of the LED Engine  |  |  |
|            | Set action/failure handlers                     | Set action and failure handlers to add functions to the MaNima Pollux.  |  |  |
|            | Set basic digital and analog contacts           | Set action handlers for digital/analog inputs.  |  |  |
|            | Remote control with MaNima Cloud                | Use the MaNima Cloud to configure the MaNima Pollux with the internet.  |  |  |
|            | Cloud Database                                  | Get insight into all owned MaNima Products in the MaNima Cloud.   |  |  |
|            | Cloud Datalogging                               | All measured parameters and saved into the MaNima Cloud.  |  |  |
|            | Cloud Back-up of configurations                 | Save configurations to quickly configure other MaNima Polluxes  |  |  |
|            | Cloud Feedback                                  | Receive status updates from a MaNima Pollux incase of potential calamities.   |  |  |
|            | INP compatible                                  | Use Industrial Network Protocols to communicate with the MaNima Pollux  |  |  |
| Industrial | UDP compatible                                  | Use UDP-Commands to communicate with the MaNima Pollux  |  |  |
| Features   | OTA software updates                            | Automatically install Over-The-Air software updates to increase reliability.  |  |  |
| reatures   | Adjust PWM-output                               | Adjust all parameters of the PWM-outputs  |  |  |
|            | Adjust PWM frequency                            | Adjust the PWM-frequency from 100Hz to 30kHz  |  |  |
|            | Set advanced digital and analog contacts        | Set action handlers for digital/analog inputs.  |  |  |
|            | Set (astronomic) timetables                     | Use timetables to set actions handlers for specific times or periodic events.   |  |  |
|            | Enable Pulse mode                               | Activate pulse mode for connector 'digital inputs 2'. Use digital inputs 2 to trigger the strobing/pulse mode of individual PWM-outputs, with a minimum pulse length of 10μs. |  |  |





### **Connection Diagram**

**Descriptions of ports from top left to bottom right:** 



12/48V DC1: Power input for power source 1. Corresponds with 'DC1 PWM Outputs'.

12/48V DC2: Power input for power source 2. Corresponds with 'DC2 PWM Outputs'.

**DC1 PWM outputs:** 4 x PWM Outputs and 3 x V+. Corresponds with '12/48V DC1 Power input'.

DC2 PWM outputs: 4 x PWM Outputs and 3 x V+. Corresponds with '12/48V DC2 Power input'.

**Analog input 1:** Input for analogue sensors. See next page for the pinout.

**Analog input 2:** Input for analogue sensors. See next page for the pinout.

**Digital in/output 1:** In- and outputs for the digital sensors. See next page for the pinout.

**Ethernet 1 and 2:** RJ45 connector Ethernet switch for connecting the Pollux to the network.

**Digital input 2 / Pulse mode (Industrial license only):** Digital input RJ45 connector.





#### **Pinout Connectors:**


| Ana | og | 1 |
|-----|----|---|
| Din |    |   |

| Pin | Function      | Max Current | Max Voltage |
|-----|---------------|-------------|-------------|
| 1   | GND           | 50mA        | 0,1V        |
| 2   | GND           | 50mA        | 0,1V        |
| 3   | NTC / LDR 4_1 | 50mA        | 3,3V        |
| 4   | NTC / LDR 3_1 | 50mA        | 3,3V        |
| 5   | NTC / LDR 2_1 | 50mA        | 3,3V        |
| 6   | NTC / LDR 1_1 | 50mA        | 3,3V        |

# Analog Analog Digital Input 1 Input 2

#### **6P6C Pinout:**


| Γ |   |   | _ |   | l |   | $ agray{1}{3}$ |
|---|---|---|---|---|---|---|----------------|
| Ш |   |   |   |   |   |   |                |
| H | 4 | 1 | 1 | 1 | 1 | 1 | ╽              |
|   | 6 | 5 | 4 | 3 | 2 | 1 |                |



#### Digital 1


| 8   |                 |             |             |
|-----|-----------------|-------------|-------------|
| Pin | Function        | Max Current | Max Voltage |
| 1   | GND             | 50mA        | 0,1V        |
| 2   | GND             | 50mA        | 0,1V        |
| 3   | Digital Out 2_1 | 50mA        | 300V        |
| 4   | Digital Out 2_2 | 50mA        | 300V        |
| 5   | Digital In 1    | 5mA         | 48V         |
| 6   | Digital in 2    | 5mA         | 48V         |
|     |                 |             |             |

#### **RJ45 Pinout:**



|  | ta |  |
|--|----|--|
|  |    |  |
|  |    |  |

| U   |                |             |             |
|-----|----------------|-------------|-------------|
| Pin | Function       | Max Current | Max Voltage |
| 1   | Digital in 2.1 | 5mA         | 48V         |
| 2   | Digital in 2.2 | 5mA         | 48V         |
| 3   | Digital in 2.3 | 5mA         | 48V         |
| 4   | Digital in 2.4 | 5mA         | 48V         |
| 5   | Digital in 2.5 | 5mA         | 48V         |
| 6   | Digital in 2.6 | 5mA         | 48V         |
| 7   | Digital in 2.7 | 5mA         | 48V         |
| 8   | Digital in 2.8 | 5mA         | 48V         |
|     |                |             |             |







## **Contact Info**

MaNima Technologies B.V.

Address:

Hastelweg 260 B 5652 CN, Eindhoven Netherlands

**Contact:** 

E: info@manima-technologies.com W: www.manima-technologies.com

T: 040 202 49 04

Chamber of Commerce registration number: 71614605

YouTube:

Link: MaNima Technologies - YouTube

